



The sensor assembly consists of a pair of PH-120C temperature sensors designed for the PH-120 fire detector. The sensors are set to a temperature above 120 ° C at which the output is switched on. The sensors are located in the engine section of the car.

Sensor connection (The sensors are connected in parallel):
Wire colors in sensor cable

Brown	+ Supply temperature sensor
Blue	GROUND temperature sensor
Green/Yellow	Temperature sensor output